



Batting Cage

Operating Procedures

1. Unlock Batting and shed areas.
2. Unlock and secure shed door and window shutters.
3. Place home plate (in batting area) at desired distance.
4. Plug in and turn on pitching machine and turn on batting area light (if needed).
5. Set pitching machine to desired speed.
6. Adjust machine angle so balls pass through the strike zone for the applicable age group (waist to midriff).
7. Show the ball to the batter then insert into the chute.
8. Wait 8 to 10 seconds before delivering the next pitch.
9. To close up, reverse steps 1 to 4.

Please report any items needing repair or replacement to the batting cage convenor.

Please take your garbage with you.